




序号	物料编码	零件名称	用量	序号	物料编码	零件名称	用量
59	000M30-006-J-0-A	connector	1	1	000M30-018-J-0-A	bolt	1
60	B-0X-00HNBR-116	o-ring D15.5-2	2	2	B-LS-35CrMo-103	bolt screw	2
61	000M30-005-J-0-A	air reservoir	1		000M30-015-J-0-A	fire pin 4.5	1
	000M30-008-J-0-A	barrel 5.5	1		000M30-017-J-0-A	fire pin 6.35	1
62	000M30-003-J-0-A	barrel 6.35	1		000M30-026-J-0-A	sleeve	1
	000M30-004-J-0-A	barrel 6.35	1	4	000M30-052-J-0-A	fire pin screw	2
63	000M30-007-J-0-A	silencer	1	5	000M30-052-J-0-A	fire pin screw	2
64	000M30-008-J-0-A	suppressor separation cover	5	6	B-LS-SUS303-197	screw M5X8	1
65	000M30-009-J-0-A	suppressor separation cover	7	7	000M30-001-J-0-A	breech	1
66	B-0X-000SI-118	o-ring D29-1	1	8	00CP1M-0110W-0-A	magnet	1
67	000M30-010-J-0-A	suppressor front cover	1	9	B-LS-35CrMo-194	screw M5X10	1
68	000M30-029-M-0-A	wood stock	1	10	B-0X-00HNBR-088	o-ring D8-1.5	2
69	B-LS-35CrMo-196	screw M4x16	1	11	000M30-024-J-0-A	released screw	1
70	000M30-028-J-0-A	trigger guard	1		000M30-039-Z-0-A	magazine 4.5	1
71	B-LS-35CrMo-195	screw M5x16	1	12	000M30-040-Z-0-A	magazine 5.5	1
					000M30-041-Z-0-A	magazine 6.35	1
				13	B-0X-000FKM-031	o-ring D7.5-1.5	1
					B-0X-000FKM-029	o-ring D7.5-1.5	1
				14	B-0X-000FKM-028	o-ring D8.5-1.5	1
					B-0X-000FKM-030	o-ring D9.5-1.5	1
					000M30-011-J-0-A	intake sleeve 4.5	1
				15	000M30-012-J-0-A	intake sleeve 5.5	1
					000M30-013-J-0-A	intake sleeve 6.35	1
				16	B-0X-00HNBR-117	o-ring D10.5-1.5	1
				17	B-LS-35CrMo-135	screw M4x25	4
				18	000M30-021-J-0-A	inflatable seat	1
				19	000M30-030-W-0-A	intake valve screw	1
				20	B-0X-00HNBR-090	o-ring D7-1.5	2
				21	000M30-025-J-0-A	filler adapter	1
				22	B-0X-000FKM-025	o-ring D11-1.5	2
				23	PR900W-020-U-0-B	gauge	2
				24	000M30-027-Y-0-A	safety insert block	1
				25	B-TH-000T9A-151	adjust spring	1
				26	B-LS-35CrMo-101	screw M4x16	3
				27	B-TH-000T9A-154	valve spring	1
				28	000M30-023-J-0-A	valve pin cover	1
				29	000M30-022-J-0-A	exhaust valve pin	1
				30	B-XD-0GCr15-139	pin D3-25	6
				31	000M30-014-J-0-A	valve	1
				32	B-0X-00HNBR-120	o-ring D18-1.5	2
				33	000M30-020-J-0-A	hit block	1
				34	B-TH-000T9A-155	hit block spring	1
				35	000M30-019-J-0-A	adjust screw nut	1
				36	000M30-037-W-0-A	sear	1
				37	B-TH-000T9A-152	sear bracket spring	1
				38	000M30-035-W-0-A	sear bracket 1	1
				39	B-XD-0GCr15-137	pin D3.5-25	1
				40	000M30-036-W-0-A	sear bracket 2	1
				41	B-LS-35CrMo-106	screw M4x4	1
				42	B-TH-000T9A-135	safety spring	1
				43	B-GZ-SUS303-008	ball D3.175	1
				44	001M22-035-J-0-A	safety	1
				45	000M30-034-W-0-A	trigger	1
				46	B-XD-0040Cr-124	pin D3-8.8	1
				47	B-TH-0065Mn-150	trigger spring	1
				48	B-LS-000045-180	trigger adjust screw	2
				49	000M30-038-S-0-A	sear pin	1
				50	B-0X-00HNBR-086	o-ring D13-2	3
				51	000M30-033-J-0-A	Balance shaft	1
				52	B-DH-00CK67-001	disc spring	12
				53	B-0X-00HNBR-091	o-ring D3-1.8	2
				54	000M30-031-J-0-A	consistent valve	1
				55	001M22-069-J-0-A	seal	1
				56	000M30-032-J-0-A	adjust pressure screw	1
				57	B-0X-00HNBR-119	o-ring D29-3.1	4
				58	B-0X-00HNBR-115	o-ring D14-2	1